FK SERIES TRANSDUCER SPECIFICATIONS

FK-263F TRANSDUCER

Page 1 of 2

Model Code / Additional Spec. Code (No entry if additional spec. code is not specified.)

FK-263F ____ - ___ - ___ / E ____ / SYS / GEO

System cable length		Mounting plate		Terminal block		Intrinsically safe		System calibration	Geotherma	al spec.
5	5m	1	DIN Rail(35mm) Mount	1	Screw type terminal block (M4)	10	Japan : DEKRA Ex ia IIC T4 Ga			
6	9m	2	Screw mount (50.8 × 50.8mm)	2	Spring lock terminal	Canada / North America : CSA C/US Class I, Division 1, Groups A,B,C,D T4				
		3	Screw mount (92 × 31mm: For VK replacement)			40	Ex ia IIC T4 Ga Class I, Zone 0, AEx ia IIC T4 Ga			
		4	Screw mount Multi-pitch (50.8×50.8mm and 92×31mm)			50	Europe : ATEX Ex ia IIC T4 Ga			
						70	China : Ex-CCC Ex ia IIC T4 Ga			
						80	Korea : KCs Ex ia IIC T4 Ga			
						B0	Taiwan : TS Ex ia IIC T4 Ga			
-				C0	Russia : TR-CU 0 Ex ia IIC T4 Ga X					
				D0	Oceania : IECEx Ex ia IIC T4 Ga					

*1 Above code shows model number of driver only. Refer to outline drawings for model number of sensor and extension cable.

SPECIFICATIONS										
CALIBRATION MATERIAL	JIS SCM440 flat surface	TEMPERATURE	Sensor : Less than ±3% of F.S.							
MEASURING RANGE	3mm to 29mm from sensor tip	CHARACTERISTIC	Extension Cable : Less than ±3% of F.S.							
SENSITIVITY*2	0.4V/mm	(TEMPERATURE DRIFT)	Condition : Gap=25mm, Target : JIS SCM440							
SENSITIVITY ERROR*2	Within ±4%		0 to 80°C (at 20°C standard)							
LINEARITY*2	Within ±250µm of 0.4V/mm straight line :		Driver : Less than ±3% of F.S.							
	(if calibrated as a system)		Loop : Less than ±4% of F.S.							
	Within ±400µm of 0.4V/mm straight line :		Condition : Gap=25mm, Target : JIS SCM440							
	(including interchangeability errors)		0 to 60°C (at 20°C standard)							
	Linear range : 26mm	OPERATING	30 to 95% RH (non-condensing, non-submerged)							
FREQUENCY RESPONCE*2	DC to 200Hz or more(-3 dB)	HUMIDITY RANGE	(Sensor body : 100%RH)							
MAX. OUTPUT VOLTAGE*2	Approx23VDC	POWER SUPPLY	-24VDC ± 10%							
SENSOR ABNORMAL	Approx0.6VDC (Sensor OPEN/Sensor SHORT)	DIELECTRIC	Between each terminals and mounting plate :							
OUTPUT VOLTAGE*2		STRENGTH OF DRIVER	1mA or less at 500VAC for one minute							
OUTPUT IMPEDANCE*2	50Ω Current 5mA(max.)	INSULATION	Between each terminals and mounting plate :							
CURRENT CONSUMPTION	Max15mA	RESISTANCE OF DRIVER	100MΩ or more at 500VDC							
(10kΩ load)		APPLICABLE WIRE	Screw type terminal block (M4) : 0.75 to 2mm ²							
OUTPUT NOISE*2	Approx. 20mVpk-pk + power supply noise	SIZE	Spring lock terminal : 0.2 to 1.5mm ²							
SENSOR TIP DIAMETER	Approx. 50mm dia.	DRIVER MASS	Approx. 200g							
CABLE DIAMETER	Approx. 3.6mm dia.	Other								
CONNECTOR DIAMETER	Approx. 7.1mm dia.									
SYSTEM CABLE LENGTH	5m or 9m									
OPERATING	Sensor : -40 to +125°C Extension Cable : -40 to +125°C									
TEMPERATURE RANGE	Driver : -40 to +80°C									
RANGE OF TEMPERATURE	E10 : -40 to +80°C (Sensor, Extension Cable & Driver)									
AT EXPLOSION PROOF	E40 : -40 to +80°C(Sensor, Extension Cable & Driver)									
CONSTRUCTION	E50 :-40 to +80°C(Sensor, Extension Cable & Driver)									
	E70 : -40 to +80°C(Sensor, Extension Cable & Driver)									
	E80 :-40 to +80°C(Sensor, Extension Cable & Driver)									
	EB0 : -40 to +80°C(Sensor, Extension Cable & Driver)									
	EC0 : -40 to +80°C(Sensor, Extension Cable & Driver) *2 The above specification apply at 25°C with -24VDC power supply and									
	ED0 : -40 to +80°C(Sensor, Extension Cable & Driver) load resistance 10kΩ and JIS SCM440 target (thickness≥5mm).									

FK SERIES TRANSDUCER

FK-263F TRANSDUCER

SPECIFICATIONS

Page 2 of 2

NOTICE 1. CALIBRATION MATERIAL 5. SENSOR INSTALLATION MODEL FK-263F Transducers are calibrated for JIS SCM440 flat Not available for rain water at out door use surface (more than 155mm dia.). It may cause the sensitivity change and insulation down. If the measured target is other than JIS SCM440 flat surface, it will present 6. CALIBRATED AS A SYSTEM a different characteristics. In such a case, calibration by the connected The sensor, extension cable and driver, which are calibrated as a system, equipment (e.g. monitor) side should be required for system operation. shall be connected with each serial No. as specified in the inspection test 2. SHIELD WIRE CONNECTION report. If this is not adhered the output characteristics may be out of Connect shield wire of signal cable (3-wire shielded cable between driver and monitor) to driver's "COM" terminal (Spring lock terminal: "Shield" terminal) and monitor's "COM" terminal. specification. LINEARITY 7. The linearity margin provides for examination result in our factory If this is not adhered to, noise may be caused. This regulated value is not applied to the examination result in the site. 3. CONNECTOR ISOLATION, etc. 8. SAFETY BARRIER The connector connecting the sensor cable and the extension cable shall In case of the intrinsically safe specification, the approved following safety be insulated with the attached insulation sleeve (transparent shrink tube) or barrier is recommended. fluoro resin insulation tape. MTL 7796-The vinyl-insulating tape shall not be used, which may cause the wiring Please use in combination with the barrier which has explosion-proof certification in the country of use. trouble in the case of temperature more than 80°C. The connector shall not be located in the oil environment. The instructions manual contains important information such as conditions 9. The oil penetration to cable through the connector may cause the sensitivity necessary for safe handling of the system. change, due to the change of the cable capacitance. Such information and conditions are important and indispensable for ensuring MEGGER TEST OF SIGNAL CABLE safety. Therefore, be sure to read the instructions manual thoroughly before 4. handling the system. If megger test is made on the signal cable (3-wire shielded cable), be sure Cable length 5.0m sensor is designed for 5m system only. 10. to discharge the charged electric load before connecting the cable to driver. Can not use for 9m system. If this caution is not adhered the driver could be dameged. 11. In the intrinsically safe system, the product cannot be used in combination with a sensor/extension cable/driver with the intrinsically safe code "/EX[]".

CONFIGURATION

